







COMMODITY		TOP SCREEN	BOTTOM SCREEN
GRAINS & OILS CON'T.			
Oats, very large		20, 13x3/4	1/13x1/2
Oats, large		18, 11x3/4	1/14x1/2
Oats, small		16, 9x3/4	1/15x1/2
Oats, Very Plump		18, 9x3/4	1/12x1/2
Oats, Very Thin		18, 9x3/4	1/14x1/2
Oats, Mo. 0-205		16, 7x3/4	1/16x1/2, 1/18x1/2
Popcorn, Japan Hulless			9, 10, 6x3/4
Popcorn		18, 19	11, 12
Popcorn, Strawberry		14	6x3/4
Popcorn, Pearl		19	11, 12, 8x3/4
Quinoa (Black, White)		7	1/15, 6x24, 1/24x1/2
Rape, Dwarf		6	4x22
Rice, unhulled, long grain		12, 7x3/4	1/15x1/2, 1/16x1/2
Rice, unhulled, short grain		12, 8x3/4	1/13x1/2, 1/14x1/2
Rice, hulled		12	14x14
Rice, Wild (FROM MINNESOTA)		12	6, 1/13
Rye		12, 7x3/4	1/16x1/2
Rye, Florida Black		11	3/64x5/16
Safflower		11x3/4	6x3/4
Sesame		1/20x1/2	1/16, 6x24
Sesame, Black		3/64x5/16	1/16, 14x14
Sorgo, Atlas		10	1/12x1/2
Sorghum		10, 1/12x1/2	6x20, 1/15
Spelt (Hulled)		16	5x3/4
Spelt (Unhulled)		20	6x3/4
Sunflower, Black Oil		19	11, 12
Sunflower,		19	11, 12
Sunflower, Large Stripped		28	13, 14
Triticale		15, 9x3/4	6x3/4
Teff		24x24, 22x22	38x38
Wheat, TR ???		12	5x3/4
Wheat, plump		14, 9x3/4	5-1/2x3/4
Wheat, thin		12, 8x3/4	1/13x1/2
Wheat, Durum		16, 10x3/4	6x3/4
Wheat, Take out Wild Radish		12	5x3/4



COMMODITY		TOP SCREEN	BOTTOM SCREEN
SMALL LEGUME SEED CONT.			
Lespedeza, Bicolor, hulled		1/13x1/2	6x18
Lespedeza, Bicolor unhulled		1/12x1/2	6x18
Lespedeza, Common, unhulled		3/64x5/16	1/16, 1/15
Lespedeza, Common, hulled		3/64x5/16	1/18
Lespedeza, Kobe, Marion unhulled		1/18x1/2	1/14, 1/12
Lespedeza, Kobe, hulled		3/64x5/16	1/16
Lespedeza, Korean, unhulled		3/64x5/16, 1/18x1/2	1/15, 1/16
Lespedeza, Korean, hulled		3/64x5/16	1/18
Lespedeza, Scricea, unhulled		1/18x1/2	1/15
Lespedeza, Scricea, hulled		3/64x5/16	6x26
Sanfoin, hulled		6x3/4	1/18x1/2
Sanfoin, unhulled		10x3/4	1/12x1/2
Sesbasia		9, 8	1/18x1/2
Trefoil, Birdfoot		3/64x5/16	6x24
Trefoil, Yellow or Black Medic, hulled		3/64x5/16	6x30
Trefoil, Yellow or Black Medic, unhulled		1/18x1/2	6x30







COMMODITY			TOP SCREEN	BOTTOM SCREEN
TREE SEED				
Birch, Black			14	6
Cedar, Red			1/18X1/2	6
Fir, Douglas			15	8, 1/15x1/2
Fir, Noble			18	1/16x1/2
Fir, Balsam Dewinged			12	1/18x1/2
Juniper			22	8x3/4
Larch, Western			8	1/14, 1/22x1/2
Locust, Honey			20	12
Locust, Black			10	6
Pine, Slash			15, 16	8, 9
Pine, Long Leaf			20, 22	12
Pine, Pitch			10	1/12
Pine, Yellow			18	6-1/2x3/4
Pine, Virginia			10	1/18x1/2
Pine, Norway			9	1/13
Pine, Jack			9	1/16
Pine, Jack			12	6
Pine, Leaf Pine			11	1/12
Pine, Red			10, 6x3/4	1/18x1/2
Pine, Ponderosa			16	8, 5-1/2x3/4
Pine, Loblolly			12, 13	1/14x1/2
Pine, Lodgepole			8	1/16, 1/17
Spruce, Engleman			7	6x21
Spruce, Black			1/13	6x24
Spruce, White			1/12, 1/15x1/2	6x21, 6x22
Sweet Gum			12	1/13

COMMODITY		TOP	BOTTOM
		SCREEN	SCREEN
VEGETABLE AND FRUIT			
Asparagus		11, 12	9
Beet, FK ??		19	9
Beet, California		20, 19	8, 9
Beet, Garden			8, 9
Broccoli		7	1/16, 20x20
Cabbage		6, 7	1/16, 1/17, 3/64x5/16
Carrot		6, 5-1/2	6x26, 6X30
Carrott, ROP ??\		8	6x24
Cauliflower		6	1/17, 1/18
Celery		1/16, 1/17	28x28, 30x30
Cucumber		16, 17	8, 9
Chicory		1/14	22x22
Cosmos		1/14x1/2	1/20
Crambe (Seakale)		13	5.5
Grape (Dry)		13	5x3/4
Lettuce		6 X 16	22x22, 24x24
Lettuce, Lehuce		6 X 20	1/18, 22x22
Lettuce, Tango		6 X 18	20x20
Lettuce, Black Simpson		6	24x24
Muskmelon		16	9
Okra		14, 15	8x3/4, 9x3/4
Onion		8, 9	1/14, 1/15
Onion, Valdalia		9	1/13
Oregano Leaves		36	28x28
Pepper		16, 18	6x3/4, 8
Pumpkin		28	18
Radish		9	1/13, 1/14
Rutabaga		6	1/14, 1/16
Spinach		8	1/15
Squash		32, 34, 36	23, 24
Squash, Butternut		28	16, 18
Strawberry Seed		16x16	28x28
Tomato		10, 11	1/12, 6
Turnip		1/16	1/20
Watermelon		24	16
Watermelon, Sugarbaby		20, 12x3/4	12
Watermelon, Garrison		26, 13x3/4	19





COMMODITY		TOP SCREEN	BOTTOM SCREEN
WILDFLOWER & NATIVE GRASS			
Acjinophila		12	6
Arburicola		10	5-1/2
Blue Stem, Big (from Colorado)		18	1/18x1/2
Blue Stem, Little (from Lousiana)		18	1/18x1/2
Blue Stem, Little (from Kentucky)		15	6x24
Blue Stem, Little (from Nebraska)		20	1/16x1/2
Blue Stem, Little (from Colorado)		20	1/18x1/2
(Schizyachyivium Scopavium)			
Blue Gamma (from Colorado)		12	6x28
(Bouteloua Gracilis)			
Broadleaf Lotus		9	1/20x1/2
Canadian Wild Rye (Elymus Canadensis)		16	1/24x1/2
Caterpillar Plant		6	1/23
Common Madia		7	1/23
Compass Plant (from Missori)		24	16
Coneflower		11, 10	1/14x1/2, 1/18x1/2
Deerbrush		All Air	All Air
Eastern Gamma Grass		17, 18	8x3/4
Jewel Flower		5-1/2	1/21
Indian Paintbrush (from Missouri)		24x24, 22x22	6x40
Indian Grass (from Kentucky)		12	6x24
Lupine, Sickle Keel		13	9
Lupine, Bi-Color		9	5-1/2
Lupine, Silver		13	9
Lupine, Moot		9	5-1/2
Little Cone Sunflower		15	8
Maximillion Sunflower		6, 7	1/17, 6x26
Meadowfoam		11	1/14
Mules Ear		9	1/24x1/2
Needle & Thread (from Colorado)		10	6x26
Pear Everlasting		Bad Sample	
Smooth Cordgrass		20	Blank

COMMODITY			TOP SCREEN	BOTTOM SCREEN
SPECIALTY CROPS				
Tobacco Seed			26x26	50x50, 60x60